Thank you for your purchase. The Exile® LED Battery Monitor allows you to easily check the status of your battery.

General Features

- **Red, Yellow and Green LED's provide a real-time visual status of your battery.**
- **Quick-Connect allows you to easily connect the EXILE® EX-1 battery charger.**
- **IP-65 Water & Dust Resistant connections & housing**

Using the LED Battery Monitor

When the LED Monitor is connected to your battery, the LED's will flicker to indicate the charge status of your battery. The LED lights draw very little current from your battery and can remain permanently connected to your battery all year around.

1. Connect the Red & Black O-ring terminals to your battery, make sure that the Red (+) connector and the Black (-) connector are carefully and correctly connected.

2. When connected, Red, Yellow and Green indicators will flicker according to the battery's charging status.
Green= 12.7V+ charge level, no action needed.
Yellow= 12.45V-12.69V charge level, charging Recommended.
Red= Below 12.44V, charge immediately.

LED Battery Monitor Overview



Photo above, showing Quick-connect of LED Monitor to EX-1 battery charger connection

Exile®

LED BATTERY MONITOR

Connects to your battery to monitor its status

Exile®

LED BATTERY MONITOR

- Red/yellow/green LEDs
- Ring terminals for easy installation
- Works with any vehicle
- Compatible w/ EX-1 charger
- IP65 water/dust-resistant

Exile®

LED BATTERY MONITOR
MODEL: EM-1

LED INDICADOR DE BATERÍA

VOYANT DE BATTERIE

LED BATTERIEANZEIGE

EXILECHARGERS.COM

Exile®

LED BATTERY MONITOR

SPECIALTY EQUIPMENT MARKET ASSOCIATION
SEMA
Serving the Motor Vehicle Aftermarket

IP65
OUTDOOR RATED

RoHS
COMPLIANT

8 56241 00373 3

Made in China